EMIL SCHMECKENBECHER
UHRENFABRIK
VILLINGEN/SCHWARZWALD
TELEFON 2365/2367

Guarantee

For Original Black Forest Cuckoo Clock

This clock has been thoroughly tested before leaving the factory and is guaranteed to be free from defects in material and workmanship under normal use for a period of one year from date of purchase by the original purchaser. If the clock does not function properly after unpacking and setting up instructions have been followed carefully, most likely the mechanism got out of adjustment due to rough handling in transit.

In this case, it is suggested the clock be sent to one of our Repair Service Stations listed on the reverse side. Packages should always be well packed and insured, and the sender's name and address being printed plainly thereon. Also include a note as to the nature of the complaint. DO NOT SEND THE PINE CONE WEIGHTS, PENDULUM OR ROOF CARVING!

This one year guarantee shall not apply in the case of damages or mechanical failure due to accidents, misuse, tampering, rough handling or shipment through the mail. Our obligation hereunder is limited to furnishing a replacement part free of charge for any part which proves defective within the one year period. It does not include the furnishing of any labor involved, such as that required to diagnose the trouble or to remove or install any such defective parts; nor does it include responsibility for any transportation expenses in connection therewith.

Upon receipt of the clock, the service station will advise whether or not the adjustment is covered under the guarantee. If not, there will be a nominal charge to cover cost of labor, return postage and handling.

EMIL SCHMECKENBECHER

Important

Your new clock, made in the Black Forest of Germany, has been carefully tested, adjusted and wound before leaving the factory. Expert clock-makers and wood carvers bring you not only an attractive item, but also a dependable time-piece.

It will give you good service, if you are following the simple instructions outlined in this leaflet.

Carton contents:

Instruction leaflet.
1 Top Ornament
1 Pendulum
2 Pine cone weights
(3 weights, if you purchased a musical cuckoo clock or a cuckoo and quail clock)
1 Clock

DO NOT THROW AWAY THE CARTON OR INSIDE PADDING UNTIL YOU HAVE FOUND ALL ACCESSORIES LISTED ABOVE!



Instructions for Assembly

1) Carefully remove clock from carton and unwrap loose accessories. Do not touch the small bag tied under the clock.

2) Put clock face down. Push clamp "A" upwards. Insert a dull instrument (screwdriver etc.) into opening "B" and gently lift up and remove the back panel.

3) Carefully remove cardboard under chime spring on back panel.

4) Pull out the two wire clamps "C" and "D" from each of the two bellows.

5) Put back panel in its place again. Push metal clamp "A" down to hold back panel closed.

6) Fasten the hand carved top ornament with the two clips unto the front of the roof.

7) Now select a place for your new clock. Put a strong nail or screw at least 7 feet above the floor, with its head tilted slightly upwards. Be sure, clock is hanging straight and flush against the wall.



8) Carefully unwrap chains from paper bag fastened at the bottom of the clock. Remove the wire that is fastened through the chains to prevent their slipping from the cog wheel, while the clock is in transit.

DO NOT TURN CLOCK UPSIDE DOWN AT ANY TIME AFTER REMOVING THIS WIRE!

Allow chains to hang freely through bottom of clock. See that the chain has no knots but is hanging down very straight.

9) **Front of clock:**
There is a little door for the cuckoo above the dial of the clock This door is held closed by a wire-hook. Turn this wire upwards to allow the door to open.
(There are two doors on musical cuckoo clocks and cuckoo and quail clocks.)

10) Hang pendulum onto wire-loop "E" and pine cone weights onto hooks "F".
Clock might now start to cuckoo; do not try to stop this; after the first full hour call, the striking mechanism will adjust itself and always be correct.

Before starting the clock, read the following:

Setting to correct time:

Turn the minute hand (long hand) slowly till the clock shows the correct time. Do not touch the hour hand (short hand). The cuckoo call will automatically adjust itself and strike the correct time. Now start your clock by gently swinging the pendulum to the side.

Winding:

After a few hours the pine cones have lowered and the rings fastened to the end of the chains have come up. (The weights will not go down at the same rate of speed. Pull the rings down till the weights are up just under the clock. Your clock is now fully wound up again.
One weight winds up the movement. One weight winds up the cuckoo-bird mechanism. (Cuckoo clocks with music have three weights. The third weight winds up the music-movement).

Adjustment:

If your clock is too fast, lower pendulum.
If your clock is too slow, move up pendulum.

REPAIR SERVICE STATIONS:

Algonquin, Ill. American Black Forest Enterprises, 110 West Chicago Street.
Brooklyn, 15 N.Y. The Clock Repair People · 299 7th Ave.
Chicago 45, ILL. Schuderer's Clock Shop · 5807 North Sacramento.
Cincinnati 2, Ohio Ken-Hav Clock Service · 408 Main Street.
Cincinnati 6, Ohio Vin-Acco Time Repairs · 2221 Fowler Street.
Detroit 5, Mich. Arlington Time Shop · 12637 E. 7 Mile Road.
Grandville, Mich. Engels Jewelry · 4031 Chicago Dr. S. W.
Grand Rapids Mich. Swierenga Jeweler · 2406 Eastern Ave. S. E.
Houston, Texas AAA Clock & Watch Rep. Clinic · 3218 Yoakum.
Idaho Falls, Id. Cole's Watch & Clock Shop · 480 North Capital Ave.
Lawton, Okla. Conners Clock Repair, 407 N 54th Street, Box 2122.
Miami, Fla. Johnson Clock Company · 37 N. W. 1st Street.
Miami Fla. Leo Hoffer, 139 N. E. 1st Street.
New York 36, N. Y. Madora Watch Service, 31 West 47 th Street.
Newark 2, New Jersey Braunschweiger Bros. · 1212 Raymond Blvd.
Phoenix, Arizona Otto Schmieder · 35 West Washington Street.
Richfield, Wis. Anton Ruf, Rt. 1.
Rochester 7, N. Y. E. W. Van Ordier · 188 Charlotte Street.
Rochester 17, N. Y. Martin Schlenker · 272 Sagamore Drive.
Salt Lake City, Utah Mount Olympus Service Company
2265 East 3900 South.
San Francisco 15, Calif. Washington Clock Co. · 2998 Washington Street.
Zeeland, Mich. Winterhalder Clock Shop · 117 West Central Ave.

20000 9. 61 WL.